

RealView[®] Debugger

Version 3.1

Essentials Guide



RealView Debugger Essentials Guide

Copyright © 2002-2007 ARM Limited. All rights reserved.

Release Information

The following changes have been made to this document.

Change History

Date	Issue	Confidentiality	Change
April 2002	A	Non-Confidential	Release v1.5
September 2002	B	Non-Confidential	Release v1.6
February 2003	C	Non-Confidential	Release v1.6.1
September 2003	D	Non-Confidential	Release v1.6.1 for RVDS v2.0
January 2004	E	Non-Confidential	Release v1.7 for RVDS v2.1
December 2004	F	Non-Confidential	Release v1.8 for RVDS v2.2
May 2005	G	Non-Confidential	Release v1.8 SP1 for RVDS v2.2 SP1
March 2006	H	Non-Confidential	Release v3.0 for RVDS v3.0
MarchApril 2007	I	Non-Confidential	Release v3.1 for RVDS v3.1

Proprietary Notice

Words and logos marked with ® or ™ are registered trademarks or trademarks owned by ARM Limited. Other brands and names mentioned herein may be the trademarks of their respective owners.

Neither the whole nor any part of the information contained in, or the product described in, this document may be adapted or reproduced in any material form except with the prior written permission of the copyright holder.

The product described in this document is subject to continuous developments and improvements. All particulars of the product and its use contained in this document are given by ARM in good faith. However, all warranties implied or expressed, including but not limited to implied warranties of merchantability, or fitness for purpose, are excluded.

This document is intended only to assist the reader in the use of the product. ARM Limited shall not be liable for any loss or damage arising from the use of any information in this document, or any error or omission in such information, or any incorrect use of the product.

Where the term ARM is used it means “ARM or any of its subsidiaries as appropriate”.

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by ARM and the party that ARM delivered this document to.

Product Status

The information in this document is final, that is for a developed product.

Web Address

<http://www.arm.com>

Contents

RealView Debugger Essentials Guide

Preface

About this book	viii
Feedback	xii

Chapter 1

About RealView Debugger

1.1	RealView Debugger	1-2
1.2	About the debugging environment	1-4
1.3	Multiprocessor debugging	1-8
1.4	The RealView Debugger documentation suite	1-9

Chapter 2

Changes to RealView Debugger

2.1	RealView Debugger command line options	2-2
2.2	Target connection and configuration	2-3
2.3	CoreSight support	2-5
2.4	Multiprocessor debugging	2-7
2.5	Cache debugging	2-9
2.6	Trace, analysis, and profiling	2-10
2.7	Simulator support	2-11
2.8	Changes to the panes	2-12
2.9	Miscellaneous changes to the GUI	2-13
2.10	Changes to CLI commands and macros	2-14
2.11	Documentation changes	2-16

2.12	Deprecated features	2-17
2.13	Obsolete features	2-19

Chapter 3

Getting Started with RealView Debugger

3.1	How to use the tutorial	3-2
3.2	Starting the tutorial	3-3
3.3	Starting RealView Debugger	3-4
3.4	Connecting to a debug target	3-6
3.5	Loading an image ready for debugging	3-11
3.6	Setting a simple breakpoint	3-14
3.7	Running the image	3-16
3.8	Unloading an image	3-18
3.9	Disconnecting from a target	3-19
3.10	Exiting RealView Debugger	3-20
3.11	Cleaning up after the tutorial	3-21
3.12	Localizing the RealView Debugger interface	3-22
3.13	Saving a debugging session	3-26

Appendix A

About Previous Releases

A.1	Changes between RealView Debugger v3.0 and v1.8	A-2
A.2	Changes between RealView Debugger v1.8 and v1.7	A-9
A.3	Changes between RealView Debugger v1.7 and v1.6.1	A-16

Preface

This preface introduces the *RealView® Debugger Essentials Guide*, that shows you how to start using RealView Debugger to debug your application programs. It contains the following sections:

- *About this book* on page viii
- *Feedback* on page xii.

About this book

RealView Debugger provides a powerful tool for debugging applications targeted at ARM® architecture-based processors and supported *Digital Signal Processors* (DSPs). This book contains:

- an introduction to the software components that make up RealView Debugger
- a step-by-step guide to getting started, making a connection to a target, and loading an image to start a debugging session
- details about ending a debugging session
- a description of the RealView Debugger desktop.

Intended audience

This book has been written for developers who are using RealView Debugger to debug applications targeted at ARM architecture-based processors and supported DSPs. It assumes that you are experienced in developing applications for ARM platforms, but does not assume that you are familiar with RealView Debugger.

Examples

The examples given in this book have all been tested and shown to work as described. Your hardware and software might not be the same as that used for testing these examples, so it is possible that certain addresses or values might vary slightly from those shown, and some of the examples might not apply to you. In these cases you might have to modify the instructions to suit your own circumstances.

The examples in this book use the programs stored in the \Examples directory in your *RealView Development Suite* (RVDS) installation root, that are targeted at ARM architecture-based processors.

In general, examples use *RealView ARMulator® ISS* (RVISS) to simulate an ARM core-based debug target. In some cases, examples are given for other debug target systems.

Using this book

This book is organized into the following chapters:

Chapter 1 *About RealView Debugger*

Read this chapter for an introduction to using this book. It describes how this book is organized, where to find specific features, and how to use the tutorial and the rest of the documentation suite.

Chapter 2 *Changes to RealView Debugger*

Read this chapter for a summary of the changes to RealView Debugger in this release.

Chapter 3 *Getting Started with RealView Debugger*

This chapter explains how to begin using RealView Debugger for the first time. This describes how to start RealView Debugger, make a connection, load an image ready to start debugging, and how to perform some basic debugging tasks.

Appendix A *About Previous Releases*

Read this chapter for a details of RealView Debugger releases v3.0, v1.8, v1.7, and v1.6.1.

Typographical conventions

The following typographical conventions are used in this book:

<i>italic</i>	Highlights important notes, introduces special terminology, denotes internal cross-references, and citations.
bold	Highlights interface elements, such as menu names. Denotes ARM processor signal names. Also used for terms in descriptive lists, where appropriate.
monospace	Denotes text that can be entered at the keyboard, such as commands, file and program names, and source code.
<u>monospace</u>	Denotes a permitted abbreviation for a command or option. The underlined text can be entered instead of the full command or option name.
<i>monospace italic</i>	Denotes arguments to commands and functions where the argument is to be replaced by a specific value.
monospace bold	Denotes language keywords when used outside example code.

Further reading

This section lists publications from both ARM Limited and third parties that provide additional information.

ARM periodically provides updates and corrections to its documentation. See <http://www.arm.com> for current errata, addenda, and Frequently Asked Questions.

ARM publications

This book is part of the RealView Debugger documentation suite. Other books in this suite include:

- *RealView Debugger User Guide* (ARM DUI 0153)
- *RealView Debugger Target Configuration Guide* (ARM DUI 0182)
- *RealView Debugger Trace User Guide* (ARM DUI 0322)
- *RealView Debugger RTOS Guide* (ARM DUI 0323)
- *RealView Debugger Command Line Reference Guide* (ARM DUI 0175).

For details on using the *RealView Compilation Tools* (RVCT), see the books in the RVCT documentation suite.

For an introduction to all the components of RVDS, see the following books:

- *RealView Development Suite Getting Started Guide* (ARM DUI 0255)
- *RealView Development Suite Glossary* (ARM DUI 0324).

For details on using RVISS, see the following book:

- *RealView ARMulator ISS User Guide* (ARM DUI 0207).

For general information on software interfaces and standards supported by ARM, see the PDF files in:

`install_directory\Documentation\Specifications\...`

See the datasheet or Technical Reference Manual for information relating to your hardware.

See the following documentation for information relating to the ARM debug interfaces suitable for use with RealView Debugger:

- *RealView ICE and RealView Trace User Guide* (ARM DUI 0155).

Other publications

For a comprehensive introduction to ARM architecture see:

Steve Furber, *ARM system-on-chip architecture* (2nd edition, 2000). Addison Wesley, ISBN 0-201-67519-6.

For the definitive guide to the C programming language, on which the RealView Debugger macro and expression language is based, see:

Brian W. Kernighan, Dennis M. Ritchie, *The C Programming Language* (2nd edition, 1989). Prentice-Hall, ISBN 0-13-110362-8.

For more information about CEVA-Oak, CEVA-TeakLite, and CEVA-Teak processors from CEVA, Inc. see <http://www.ceva-dsp.com>.

Feedback

ARM Limited welcomes feedback on both RealView Debugger and its documentation.

Feedback on RealView Debugger

If you have any problems with RealView Debugger, submit a Software Problem Report:

1. Select **Send a Problem Report...** from the RealView Debugger **Help** menu.
2. Complete all sections of the Software Problem Report.
3. To get a rapid and useful response, give:
 - a small standalone sample of code that reproduces the problem, if applicable
 - a clear explanation of what you expected to happen, and what actually happened
 - the commands you used, including any command-line options
 - sample output illustrating the problem.
4. Email the report to your supplier.

Feedback on this book

If you have any comments on this book, send an email to errata@arm.com giving:

- the document title
- the document number
- the page number(s) to which your comments apply
- a concise explanation of your comments.

General suggestions for additions and improvements are also welcome.

Chapter 1

About RealView Debugger

This chapter introduces RealView® Debugger. It explains how the debugger provides a development environment for embedded systems applications using ARM® architecture-based processors and supported *Digital Signal Processors* (DSPs).

This chapter contains the following sections:

- *RealView Debugger* on page 1-2
- *About the debugging environment* on page 1-4
- *Multiprocessor debugging* on page 1-8
- *The RealView Debugger documentation suite* on page 1-9.

1.1 RealView Debugger

RealView Debugger enables you to debug your embedded applications and to have complete control over the flow of the execution so that you can quickly isolate and correct errors.

1.1.1 RealView Debugger concepts and terminology

The following terminology is used throughout the RealView Debugger documentation suite to describe debugging concepts:

Code window

The *Code window* is the starting point for all your debugging tasks and gives you access to features in the product. It displays connection state information and source code views, gives access to other windows, handles CLI commands, and displays debugger messages.

Connection The link between the debugger and the target. RealView Debugger enables you to connect to one or more targets, depending on your application debugging requirements.

———— **Note** —————

If your development platform contains a DSP, then you must have a DSP debugging license to connect to that DSP.

Debug Configuration

A *Debug Configuration* defines a debugging environment for your development platform.

Debug Interface

The *Debug Interface* identifies the targets on your development platform, and provides the mechanism that enables RealView Debugger to communicate with those targets. The Debug Interface corresponds directly to a piece of hardware or a software simulator.

Development Platform

The *Development Platform* contains the components, either hardware or simulated, that you are using to develop your application. It can include:

- a base board, such as an Integrator/CP
- peripherals
- one or more ARM architecture-based processors
- CoreSight™ components

- one or more DSPs.

DSP

RealView Debugger has been developed to provide full debugging functions when working with a range of targets, including *Digital Signal Processors* (DSPs).

DSP-based debugging is a separately licensed feature of RealView Debugger.

OS-awareness

OS-awareness is a feature provided by RealView Debugger that enables you to:

- debug applications running on an embedded OS development platform, such as a *Real Time Operating System* (RTOS)
- present thread information and scope some debugging operations to specific threads.

You must obtain and install the required OS-awareness plug-in.

Target

A *Target* is the part of your development platform to which RealView Debugger can connect, and on which debugging operations can be performed. A target can be:

- A runnable target, such as an ARM architecture-based processor or a DSP. When connected to a runnable target, you can perform execution-related debugging operations on that target, such as stepping and tracing.
- A non-runnable CoreSight component. CoreSight components provide a system-wide solution to real-time debug and trace.

These can be hardware or software targets.

See also

- *CoreSight support* on page 2-5.

1.2 About the debugging environment

RealView Debugger uses a three-tier environment to debug applications:

- debugger software
- a debug interface layer, incorporating the Debug Interface
- the target.

RealView Debugger uses connection information in a Debug Configuration to describe:

- how the debugger connects to the target
- information required to use that connection
- the processor type of the target.

A single RealView Debugger instance can deal with multiple simultaneous connections.

This section describes the RealView Debugger debugging environment.

1.2.1 Graphical User Interface

The *Graphical User Interface* (GUI) gives access to the main features of the debugger, command processing, and one or more Code windows.

1.2.2 Command Line Interface

The *Command Line Interface* (CLI) gives access to many of the features of the debugger through RealView Debugger commands. This enables you to create command scripts to automate debugging. You can access the CLI from the GUI, or run RealView Debugger in command-line mode. Some features are not available when running RealView Debugger in command-line mode.

1.2.3 Debug Interface

RealView Debugger works with hardware and software targets. The interface between RealView Debugger and a target is provided by a Debug Interface. RealView ICE is an example of a hardware Debug Interface. RealView ARMulator[®] ISS and Instruction Set System Model are examples of a software Debug Interface.

Each Debug Interface processes requests from the client tools to the target. A Debug Interface might be a JTAG interface, a simulator, or a ROM monitor.

RealView ICE and RealView Trace

RealView ICE enables you to debug a hardware development platform containing one or more ARM architecture-based processors and supported DSPs. You can connect to a RealView ICE unit using either a USB port or your local network.

With the addition of a RealView Trace unit, you can also perform tracing and analysis of:

- processors containing an *Embedded Trace Module*[™] (ETM)
- development platforms containing an *Embedded Trace Buffer*[™] (ETB[™])

Note

You must purchase RealView ICE and RealView Trace separately.

ARM Ltd. Direct Connection for Versatile Platform for ARM926EJ-S (USB)

RealView Debugger provides support to connect to the onboard *RealView ICE Micro Edition* (RVI-ME) debug interface on the Versatile Platform for ARM926EJ-S[™] development board. This support is provided as an option when you install RealView Development Suite.

Note

You must purchase the Versatile Platform for ARM926EJ-S development board separately.

Note

You cannot create a new ARM Ltd. Direct Connection Debug Configuration, or copy and delete the default ARM Ltd. Direct Connection Debug Configuration.

Instruction Set System Model

Instruction Set System Model (ISSM) simulates the following processors:

- Cortex[™]-A8
- Cortex-M1
- Cortex-M3
- Cortex-R4.

ISSM runs on the same host computer as the debugger.

Real Time System Model

A *Real Time System Model* (RTSM) contains a hard-coded system containing one or more specific simulated processors. When you attempt to connect to an RTSM target, RealView Debugger starts up the RTSM session before connecting to that target.

Note

If you want to create your own RTSMs, you must purchase the RealView System Generator application.

SoC Designer

Models created with RealView SoC Designer can be debugged using RealView Debugger. You can debug a SoC Designer model by either:

- launching RealView Debugger from SoC Designer Simulator to debug the model you are currently viewing
- creating a SoC Designer Debug Configuration in RealView Debugger.

Note

You must purchase RealView SoC Designer separately.

RealView ARMulator ISS

RealView ARMulator ISS (RVISS) is an *Instruction Set Simulator (ISS)*. It simulates the instruction sets and architecture of ARM processors, together with a memory system and peripherals. You can extend it to simulate other peripherals and custom memory systems.

RVISS runs on the same host computer as the debugger, and includes facilities for communicating with the debugger.

Note

RVISS is not the same as the *ARM Developer Suite™ (ADS)* ARMulator supplied with previous releases of RealView Debugger.

See also

- Chapter 3 *Target Connection* in the *RealView Debugger User Guide*
- the following in the *RealView Debugger Target Configuration Guide*:
 - Chapter 2 *Customizing a Debug Interface configuration*
 - Chapter 3 *Customizing a Debug Configuration*.
- *RealView Development Suite Getting Started Guide*
- *RealView ARMulator ISS User Guide*.

1.2.4 Persistence information

RealView Debugger maintains persistence information to enable you to halt a debugging session and resume at a later date. This means that the debugger can remember your working environment including:

- current target connections
- desktop settings, for example all windows and panes that are currently displayed.

1.3 Multiprocessor debugging

The RealView Debugger enables you to debug multiprocessor applications, which can be:

- all ARM architecture-based processors
- a mixture of ARM architecture-based processors and DSPs.

The processors can be all hardware, all simulated, or a mixture of both.

RealView Debugger supports such multiprocessor debugging by maintaining connections to multiple targets through one or more Code windows. When working with multiple processors, you can use one Code window to cycle through the connected targets, or multiple Code windows to view different targets.

1.3.1 DSP debugging

RealView Debugger provides support for debugging the following DSPs:

- CEVA-Oak
- CEVA-Teaklite (revisions B and C)
- CEVA-Teak (revisions A and B)
- CEVA-Teak on the Samsung Scorpion II
- StarCore SC1200.

DSP debugging requires separately purchased licenses.

1.3.2 See also

- *About the debugging environment* on page 1-4
- Chapter 7 *Debugging Multiprocessor Applications* in the *RealView Debugger User Guide*
- Chapter 2 *Customizing a Debug Interface configuration* in the *RealView Debugger Target Configuration Guide*
- *RealView Development Suite Getting Started Guide*.

1.4 The RealView Debugger documentation suite

The other books that make up the RealView Debugger documentation suite are:

- *RealView Debugger User Guide*
- *RealView Debugger Target Configuration Guide*
- *RealView Debugger Trace User Guide*
- *RealView Debugger RTOS Guide*
- *RealView Debugger Command Line Reference Guide*.

The following description explains how you might use the books:

1. For a comprehensive description of the debugging features available in RealView Debugger, see the *RealView Debugger User Guide*. This describes, in detail, how to debug your images and how to configure RealView Debugger to customize your working environment. It also describes the features available for debugging multiple targets.

———— **Note** —————

For information on using RealView Debugger on Red Hat Linux platforms, see Appendix E *RealView Debugger on Red Hat Linux* in the *RealView Debugger User Guide*.

2. *RealView Debugger Target Configuration Guide* describes how to customize existing Debug Configurations that are set up in the base product, and how to create your own custom Debug Configurations. It also describes how to create the files required to program Flash.
3. If you have the appropriate trace hardware, you can perform RealView Debugger tracing, which is described in the *RealView Debugger Trace User Guide*.
4. If you have the appropriate plug-ins, you can debug OS applications using the OS-awareness features in RealView Debugger. These features are described in the *RealView Debugger RTOS Guide*.
5. If you want to use the RealView Debugger *Command Line Interface (CLI)* to control your debugging tasks, the *RealView Debugger Command Line Reference Guide* provides a detailed description of every CLI command and includes examples of their use.

See the installation notes delivered with your product for details on installing RealView Debugger.

Chapter 2

Changes to RealView Debugger

This chapter describes the changes between RealView® Debugger v3.1 and the previous release, RealView Debugger v3.0. It contains the following sections:

- *RealView Debugger command line options* on page 2-2
- *Target connection and configuration* on page 2-3
- *CoreSight support* on page 2-5
- *Multiprocessor debugging* on page 2-7
- *Cache debugging* on page 2-9
- *Trace, analysis, and profiling* on page 2-10
- *Simulator support* on page 2-11
- *Changes to the panes* on page 2-12
- *Miscellaneous changes to the GUI* on page 2-13
- *Changes to CLI commands and macros* on page 2-14
- *Documentation changes* on page 2-16
- *Deprecated features* on page 2-17
- *Obsolete features* on page 2-19.

If you are using RealView Debugger on Red Hat Linux, see Appendix E *RealView Debugger on Red Hat Linux* in the *RealView Debugger User Guide*.

2.1 RealView Debugger command line options

The command line options available when starting RealView Debugger have been modified and extended, as follows:

- All options now accept a double hyphen prefix (--). However, you can still use the single hyphen prefix (-).
- The following options have been added to support project templates:
 - --no_project
 - --project
 - --reinitialize_workdir
 - --workdir.
- Many options have new names:
 - --image is an alias of --exec
 - --journal is an alias of --jou
 - --no_logo is an alias of --no logo
 - --no_workspace and --no_aws are aliases of --aws==
 - --script is an alias of --inc
 - --target is an alias of --init
 - --workspace is an alias of --aws.The original names are still supported.

2.1.1 See also

- *Starting RealView Debugger from the command line* on page 2-2 in the *RealView Debugger User Guide*.

2.2 Target connection and configuration

This section describes the improvements to target connection and configuration.

2.2.1 The Connection Control window

The Connection Control window has been renamed to the Connect to Target window, to match the menu option on the **Target** menu. In addition, the window has been re-engineered to simplify the connection and configuration of debug targets:

- Targets are grouped under the Debug Interface used to access them, such as RealView ICE. The following target groupings are available:

Target Provides a list of all targets that are accessible through each type of Debug Interface.

Configuration

Lists the targets for each Debug Configuration that you create. A single Debug Configuration corresponds to a single development platform. The Debug Configurations are listed under each type of Debug Interface to which they relate.

The chosen grouping persists between your debugging sessions.

- You can now add, copy, rename, and delete Debug Configurations in a single operation, without having to use the Connection Properties window. However, the Connection Properties window is still available for customizing your Debug Configurations, such as setting up OS awareness and assigning *Board/Chip Definition* (BCD) files.
- If your development platform contains CoreSight™ components, then those components are included in the target list for the related Debug Configuration.
- The RVISS localhost connection entry has been removed. Connecting to RVISS targets is performed in a similar way to other targets. RVISS target connections now show the simulated processor name, for example:

```
ARM7TDMI@RVISS
```

See also

- *CoreSight support* on page 2-5
- *Connecting to a debug target* on page 3-6
- Chapter 3 *Target Connection* in the *RealView Debugger User Guide*.

2.2.2 Recent connections list

As you establish connections to your targets, the connection name for that target is added to a recent connection list. This list shows the last 10 connections, which you can access from:

- A new **Home Page** tab in the Code window. With a single mouse click you can now connect to frequently used targets without having to use the Connect to Target window.

You must still use the Connect to Target window if you want to:

- add, copy, rename, customize, and delete Debug Configurations
- connect to, and disconnect from, multiple processors in a single operation
- connect using a Connect Mode.
- disconnect using a Disconnect Mode.

- A **Recent Connections** submenu on the Code Window **Target** menu.

———— **Note** —————

The **Home Page** tab also lists the last 10 images that you have loaded, so that you can load an image with a single mouse click. These can also be accessed from the **Recent Images** submenu on the Code Window **Target** menu.

2.3 CoreSight support

RealView Debugger provides support for development systems that contain CoreSight components. The following CoreSight components are supported:

- CoreSight Debug components:
 - A *Debug Access Port* (DAP) for connecting a Debug Interface unit to the target, and comprises a *JTAG Debug Port* (JTAG-DP) and *JTAG Access Port* (JTAG-AP).
 - An *Embedded Cross Trigger* (ECT) to specify cross triggering between multiple targets, and comprises *Cross Trigger Interface* (CTI) and *Cross Trigger Matrix* (CTM).
- CoreSight Trace components:
 - Sources generate trace data, and include the *Embedded Trace Macrocell™* (ETM) and *AHB Trace Macrocell* (HTM).
 - Sinks are the end points for trace data on the SoC, and include the *Embedded Trace Buffer™* (ETB™) and *Trace Port Interface Unit* (TPIU).
 - Links provide connection, triggering, and flow of trace data, and include the Trace funnel.
 - Control and access components configure, access, and control the generation of trace, and include DAP and ECT. They do not generate or process trace data.

————— **Note** —————

In this release, you can collect trace only from one ETM trace source in a multiple trace source system. Trace capture from an HTM is not supported in this release.

CoreSight components, except for the CTM, are visible in the Connect to Target window for connections through a RealView ICE unit. The Configuration grouping shows a basic relationship between the CoreSight components and the runnable targets.

You can connect to a CoreSight component in the same way that you connect to a target processor. However, all execution-related features are disabled and the Code window shows a limited view as follows:

- the register view in the Register pane
- the memory view in the Memory pane, if appropriate.

2.3.1 See also

- *Configuring CoreSight embedded cross triggering* on page 7-32 in the *RealView Debugger User Guide*

- *Customizing a RealView ICE Debug Interface configuration* on page 2-3 in the *RealView Debugger Target Configuration Guide*
- *Appendix B Setting up the Trace Software* in the *RealView Debugger Trace User Guide*.

2.4 Multiprocessor debugging

The following changes have been made to multiprocessor debugging:

- Support for cross trigger-related CoreSight components is available.
- RealView Debugger v3.0.SP1 provided a major enhancement to the Synchronization Control window and related CLI commands. These enhancements are now documented in the RealView Debugger v3.1, and include the following changes:

- The Synchronization Control window has been re-engineered. The synchronization and cross-triggering features are available on the following tabs:

Actions This is a new tab, which enables you to synchronize the following actions:

- image load, reload, and unload
- reset the target processor
- reset the PC
- set the PC
- load a binary file.

Execution

This tab enables you to synchronize the Step, Run, and Stop operations.

Cross Triggering

This tab enables you to set up cross triggering for multiple targets. Although this appears on the Synchronization Control window, synchronization and cross triggering can be set independently.

- A new SYNCHACTION command is also available to specify the synchronization of actions that are available on the **Actions** tab of the Synchronization Control window.
- The OPTION,pendmode command OPTION,pendmode, which enables you to specify the pend mode for CLI commands when debugging synchronized processors

2.4.1 See also

- *CoreSight support* on page 2-5
- Chapter 7 *Debugging Multiprocessor Applications* in the *RealView Debugger User Guide*

- Chapter 2 *RealView Debugger Commands* in the *RealView Debugger Command Line Reference Guide*.

2.5 Cache debugging

Cache debugging is supported as described in the following sections:

2.5.1 Supported processors

Cache debugging support is provided for the following processors:

- ARM1136
- ARM1156
- Cortex™-A8.

2.5.2 Memory pane coloring scheme

The Memory pane context menu has an option to display a caching color scheme. Cached memory areas are colored according to the level (L1 or L2) and state (clean or dirty) of the cache.

See also

- *Viewing memory contents* on page 13-45 in the *RealView Debugger User Guide*.

2.5.3 Cache-related CLI commands and predefined macros

The following new cache-related CLI commands are available:

- CACHEFIND, which searches for an address within the cache
- CACHEINFO, which displays details about the cache
- CACHELINE, which prints information about a specific cache line.

The following new cache-related predefined macros are available:

- `cache_find_set`, which returns the set index associated with a specified address in the cache
- `cache_find_way`, which returns the way index associated with a specified address in the cache.

See also

- the following in the *RealView Debugger Command Line Reference Guide*:
 - Chapter 2 *RealView Debugger Commands*
 - Chapter 3 *RealView Debugger Predefined Macros*.

2.6 Trace, analysis, and profiling

The major change to the trace, analysis, and profiling features is the support for trace-related CoreSight components.

2.6.1 See also

- *CoreSight support* on page 2-5
- *RealView Debugger Trace User Guide*.

2.7 Simulator support

The following simulated targets are now supported:

- An MPCore™ simulated target is now supported in *RealView ARMulator® ISS* (RVISS). However, this simulates only a single processor.
- RVISS Debug Configurations are provided to simulate the following processors:
 - ARM7TDMI®
 - ARM926EJ-S™
 - ARM1176JZF-S™.

You can connect to these without having to configure them.

- The following new *Instruction Set System Model* (ISSM) simulator are now supported:
 - Cortex-M1
 - Cortex-R4.

In addition, the Cortex-A8 and Cortex-M3 models have been enhanced.

A single ISSM Debug Interface is provided, which you can configure to any of these processors. If you want to simulate additional processors, you must create a new ISSM Debug Configuration for each processor.

- RealView SoC Designer models can be debugged. RealView Debugger starts RealView SoC Designer Simulator automatically when you attempt to connect to a target in a SoC Designer model. Connections to other targets in the same model can then be established.
- *Real Time System Models* (RTSMs) can be debugged. If you want to create an RTSM from your own SoC Designer models, then you must purchase the RealView System Generator software.

2.7.1 See also

- *RealView Debugger Target Configuration Guide*.

2.8 Changes to the panes

The following changes have been made to the RealView Debugger panes:

- The display format for undocked panes has changed. The related connection and associated color box are now displayed at the bottom of the pane.
- The pane menu buttons have been removed.
- Pane operations are now provided on the context menu.
- The Call Stack pane now contains only the **Call Stack** tab.
- The **Locals**, **Statics**, and **This** tabs are now available in the new Locals pane.
- The Memory pane has been re-engineered:
 - A pane toolbar has been added, which contains fields to specify the start address, the number of columns, the data size, and the format of memory cells.
 - A new cache coloring scheme has been added.
 - You can now set values of memory locations by entering ASCII characters in the ASCII view.
 - When entering ASCII characters at a memory location, precede the characters by a single quote. You can enter as many characters as the currently selected data size implies.

2.8.1 See also

- *Overview of RealView Debugger windows and panes* on page 1-3 in the *RealView Debugger User Guide*.

2.9 Miscellaneous changes to the GUI

The following changes have been made to the RealView Debugger GUI:



- The **Src** tab has been removed from Code window.
- The **Dsm** tab has been renamed to **Disassembly**.
- The **Map** tab in the Process Control pane has been renamed to **Memory Map**.
-  • A new **Show Next Statement** button has been added to the Debug toolbar. This shows the location of the PC in the **Disassembly** tab or a source file tab, and is identified by a yellow arrow in the margin with a red box around the instruction or line of source.
- A Scripts toolbar is now provided, which enables you to quickly add, run and delete command scripts, shown in Figure 2-1.



Figure 2-1 Scripts toolbar

-  • A new button to reset the target processor has been added to the Connect toolbar.
- Some buttons have been removed from the Debug toolbar.
- Many changes have been made to the context menus, including:
 - renaming of the menu options for setting breakpoints and tracepoints
 - removal of some less useful menu options.
- The following **ARM on the Web** menu options are now available on the **Help** menu:
 - **Goto ARM Technical Support**
 - **Goto ARM Development Tool FAQs**
 - **Goto ARM Technical Support Downloads**
 - **Goto ARM PDF Documentation**
 - **Goto ARM Self Help Forums.**

2.9.1 See also

- Chapter 1 *RealView Debugger Features* in the *RealView Debugger User Guide*.

2.10 Changes to CLI commands and macros

This section describes the changes that have been made to CLI commands and macros.

2.10.1 Changes to CLI commands

The following new CLI commands are provided:

- cache-related commands
- COREINFO, which enables you to display information about the current target
- CORESTATE, which enables you to display the execution state of the current target
- REGINFO, which enables you to display details of the registers available for the current target
- synchronization-related commands
- VA2PA, which enables you to convert a virtual address to a physical address.

See also

- *Multiprocessor debugging* on page 2-7
- *Cache-related CLI commands and predefined macros* on page 2-9
- Chapter 2 *RealView Debugger Commands* in the *RealView Debugger Command Line Reference Guide*.

2.10.2 Changes to macros

This sections describes the changes that have been made to macros.

New predefined macros

New cache-related predefined macros are provided.

Using integer variables

You can now substitute the value of an integer variable in a CLI command before the command is executed. The value is converted to hexadecimal. To do this, you must enclose the variable name between the characters `{` and `}`, for example:

```
int num;  
num = 1;  
$FOPEN 150, "C:\\myfiles\\myfile${num}.txt"; // substitution
```

The filename in this example is `myfile0x1.txt`.

See also

- *Cache-related CLI commands and predefined macros* on page 2-9
- *Using variable substitution in commands within a macro* on page 16-7 in the *RealView Debugger User Guide*
- Chapter 3 *RealView Debugger Predefined Macros* in the *RealView Debugger Command Line Reference Guide*.

2.11 Documentation changes

The following changes have been made to the RealView Debugger documentation:

- All documentation has been updated to reflect the changes to the RealView Debugger GUI and CLI commands.
- The *RealView Debugger Target Configuration Guide* has been restructured. A new chapter has been included, which provides a tutorial on memory mapping.
- The *RealView Debugger Trace User Guide* has been restructured. A tutorial has been included, which is to be used in conjunction with the `trace.c` program. The program is provided with *Application Note 168 Tracing with RVD*. To obtain the program, navigate to the Application Notes page under Documentation on the ARM website (<http://www.arm.com>).
- The chapter that describes target connection in the *RealView Debugger Target Configuration Guide* has been incorporated into the *RealView Debugger User Guide*.

2.12 Deprecated features

The following features are deprecated in RealView Debugger v3.1:

- The /B, /H, and /W qualifiers to the following commands are deprecated:
 - DUMP
 - FILL
 - MEMWINDOW
 - SEARCH
 - SETMEM
 - TEST.

Use the /8, /16, and /32 qualifiers as appropriate.

- The rawb and rawh qualifiers to the following commands are deprecated:
 - READFILE
 - VERIFYFILE
 - WRITEFILE.

Use the raw8 and raw16 qualifiers as appropriate.

- The following command qualifiers are deprecated:
 - ANALYZER,edit_properties
 - ETM_CONFIG,addronly
 - ETM_CONFIG,fulltrace
 - TRACEBUFFER,amount.
- The following Workspace settings and groups are deprecated:
 - _ctrl settings group
 - Vi setting.
- The following top-level Debug Configuration settings in Connection Properties are deprecated:
 - the Project setting
 - the Remote settings group
 - the Shared setting (this is not the same as the Shared setting in the Attributes group of a Memory_block definition).

2.12.1 See also

- Appendix A *Workspace Settings Reference* in the *RealView Debugger User Guide*
- Appendix A *Connection Properties Reference* in the *RealView Debugger Target Configuration Guide*

- *Alphabetical command reference on page 2-13 in the RealView Debugger Command Line Reference Guide.*

2.13 Obsolete features

The following features are obsolete in RealView Debugger v3.1:

- Remote RealView ARMulator[®] ISS (RVISS) connection using RealView Simulator Broker.
- Connections to *Remote Debug Interface* (RDI) targets, which includes:
 - Multi-ICE[®]
 - Agilent Debug Interface
 - Remote_A.
- ETMv2 is no longer supported.
- The following CLI commands have been removed:
 - NAMETRANSLATE
 - PATHTRANSLATE.

Chapter 3

Getting Started with RealView Debugger

This chapter gives step-by-step instructions to start debugging an application with RealView® Debugger. It is in the form of a tutorial, where each task assumes that you have performed the preceding tasks. This chapter contains the following sections:

- *How to use the tutorial* on page 3-2
- *Starting the tutorial* on page 3-3
- *Starting RealView Debugger* on page 3-4
- *Connecting to a debug target* on page 3-6
- *Loading an image ready for debugging* on page 3-11
- *Setting a simple breakpoint* on page 3-14
- *Running the image* on page 3-16
- *Unloading an image* on page 3-18
- *Disconnecting from a target* on page 3-19
- *Exiting RealView Debugger* on page 3-20
- *Cleaning up after the tutorial* on page 3-21
- *Localizing the RealView Debugger interface* on page 3-22
- *Saving a debugging session* on page 3-26.

3.1 How to use the tutorial

The tutorial describes the main tasks required to begin debugging an application. It assumes that you already have an image to debug. The classic Dhrystone benchmark is provided as an example with *RealView Development Suite* (RVDS), which has a prebuilt image. This image is used in the tutorial.

The Dhrystone example is installed in the directory:

```
install_directory\RVDS\Examples\...\dhrystone
```

The main ... \dhrystone directory contains:

- the subdirectories ... \Debug and ... \Release containing prebuilt debug and release images of *dhrystone.axf*
- C source files required to build the image
- build files, for building the image with *RealView Compilation Tools* (RVCT) supplied with RVDS.

Before you start the tutorial, make a copy of the Dhrystone example, and use your copy during the tutorial.

3.1.1 See also

- *Starting the tutorial* on page 3-3.

3.2 Starting the tutorial

Begin by making a copy of the source files provided so that the tutorial is self-contained and the installed example files are untouched:

1. Create a new directory called `\Tutorial`, in your RVDS examples directory:

```
install_directory\RVDS\Examples\...\windows\Tutorial
```

This is the tutorial project *base directory*.

2. Copy the following files from the examples directory, that is `...\dhrystone`, into your new tutorial directory:
 - C source files `dhry.h`, `dhry_1.c`, and `dhry_2.c`
 - the build files:
 - `dhry.bat`
 - `dhry.mk`
 - the Debug directory.

You can complete this tutorial using the files you have copied. You do not have to change any of these files or amend any configuration files.

3.3 Starting RealView Debugger

To start RealView Debugger, from Windows, select:

Start → Programs → ARM → RealView Development Suite v3.1 → RealView Debugger v3.1

The first time you run RealView Debugger after installation, it creates a unique working directory for you to store your personal files, debugger settings, and target configuration files. RealView Debugger then creates files in, or copies files into, this directory ready for your first debugging session. The location depends on your host platform:

- On Windows, the default location of the home directory is in:
C:\Documents and Settings*userID*\Application Data\ARM\rvdebug*version*
If a user ID is not available, then RealView Debugger creates a general-purpose directory called *owner*.
- On Red Hat Linux, the location is in *~/rvd*.

The main RealView Debugger window is known as the Code window. The default layout of the Code window is shown in Figure 3-1 on page 3-5.

———— **Note** ————

You might want to position and resize the main RealView Debugger window to your requirements. Also, resize the panes as required. RealView Debugger remembers the position and size of the window and panes between debugging sessions.




Figure 3-1 Default Code window

3.4 Connecting to a debug target

Before you can load an image to a debug target, you must connect to the target. You access connections using the Connect to Target window.

———— Note ————

Be aware that the default connection mode stops the target.

3.4.1 How to display the Connections window

To display the Connect to Target window, click **Connect to Target...** in the **Home Page**.

The Connect to Target window is displayed, shown in Figure 3-2.




Figure 3-2 Connect to Target window

See also

- *Elements of the Connect to Target window* on page 3-7
- *Chapter 3 Target Connection* in the *RealView Debugger User Guide*.

3.4.2 Elements of the Connect to Target window

The Connect to Target window includes a tree control, which comprises:

Debug Interface

This group shows the type of debug target interface used to support the connection. For RealView ICE, this is the ARM® JTAG debug tool for embedded systems.

Debug Configuration

A Debug Configuration identifies the targets that are available on the associated development platform. A Debug Configuration enables you to set up a custom debugging environment.

Target grouping

You can display the targets using the following groupings:

Target All the targets are shown as a single list in each Debug Interface. The targets are listed in the order of the associated Configuration name, shown in Figure 3-3.




Figure 3-3 Example Connect to Target window (Target group)

Configuration

The targets are listed under the name of the associated Debug Configuration, shown in Figure 3-4 on page 3-8. You can have multiple Debug Configurations for the same development platform. If you have multiple debugging platforms, then you

must create a separate Debug Configuration for each platform. A Debug Configuration enables you to set up a custom debugging environment.




Figure 3-4 Example Connect to Target window (Configuration group)

———— **Note** ————

A Synchronization Control window is also available for debugging multiprocessor applications.

See also

- the following in the *RealView Debugger User Guide*:
 - Chapter 3 *Target Connection*
 - Chapter 7 *Debugging Multiprocessor Applications*.

3.4.3 Making a connection

This tutorial uses the RealView Instruction Set Simulator (RVISS) Debug Interface. However, if you want to connect to a hardware target, first make sure your debug hardware and target system are powered on, and configured as described in your debug hardware User Guide.

To connect to a debug target, do the following:

1. Select **Connect to Target...** from the **Target** menu to display the Connect to Target window. An example is shown in Figure 3-2 on page 3-6.

2. Select **Configuration** from the Grouped By drop-down list.

———— **Note** —————

It is recommended that you add and configure a Debug Configuration using the **Configuration** grouping.

3. Expand the RealView Instruction Set Simulator (RVISS) Debug Interface. The RVISS, RVISS_1, and RVISS_2 Debug Configurations are available.
4. Expand the RVISS Debug Configuration to show the target processor available for the configuration. For the RVISS Debug Configuration, the target is called ARM7TDMI.
5. Double-click on the ARM7TDMI target processor to connect.

With the connection established, your Code window is updated, shown in Figure 3-5 on page 3-10:

- The Code window title bar is updated with the name of the current connection. In this example, the connection name is ARM7TDMI@RVISS. The connection name is also used in floating panes to identify the connection to which the pane contents relate.
- The color box is updated with a color for the connection. This color is also used in floating panes to identify the connection to which the pane contents relate.
- The **Home Page** is updated as follows:
 - The connection is added to a Recent Connections... list. For this example, the connection entry is ARM7TDMI@RVISS (connected).

———— **Note** —————

RealView Debugger adds an entry to this list each time you connect to a different target, up to 10 a maximum of ten connections.

 - A **Load Image...** entry is added, to enable you to load an image to the target.
- The **Cmd** tab of the Output pane displays connection details.
- Panes are updated with debug information, for example the Process Control pane shows process information for the connected target.




Figure 3-5 Home Page with a connection

The default configuration files installed as part of the base product enable you to connect to an ARM7TDMI®, ARM926EJ-S™, and an ARM1176JZF-S™ simulated core using RVISS.

See also

- the following in the *RealView Debugger User Guide*:
 - Chapter 3 *Target Connection*
 - Chapter 7 *Debugging Multiprocessor Applications*.

3.5 Loading an image ready for debugging

When you have connected to a suitably configured debug target you are ready to load your image for debugging.

3.5.1 Loading an image directly

To load an image directly to your debug target:

1. Click **Load Image...** in the **Home Page** to display the Select Local File to Load dialog box.

———— **Note** —————

Do not change any default settings in the Select Local File to Load dialog box.

2. Locate the `dhrystone.axf` image in your Tutorial directory (see *Starting the tutorial* on page 3-3):

`install_directory\RVDS\Examples\...\Tutorial\Debug`

3. Click **Open**.

The image is loaded to the debug target.

———— **Note** —————

In the Code window Text Coloring and source code line numbering are enabled by default.

When you load an image, the debugger updated the Code window with the image details, shown in Figure 3-6 on page 3-12:

- Inserts the source filename, for the current context, in the File field of the Find toolbar.
- Inserts a blue hyperlink for the loaded image in a **Recent Images...** list on the **Home Page**. You can click this hyperlink if you want to load the image in future.

———— **Note** —————

RealView Debugger adds an entry to this list each time you load an image, up to 10 a maximum of ten images.

- Updates the Code window panes as appropriate, for example, it updates the process information in the Process Control pane.

- Displays the load command, used by RealView Debugger to load the image, in the **Cmd** tab in the Output pane.




Figure 3-6 Code window with image loaded

If an image is compiled to generate debug information, that is using the `--debug` switch, loading the image enables RealView Debugger to gather debug information about the image and the associated source files. In the `dhrystone` example, the source file `dhry_1.c` is opened into a source tab when you load the image because it has the context.

See also

- Chapter 4 *Loading Images and binaries* in the *RealView Debugger User Guide*.

3.5.2 Loading multi-image applications to a single debug target

If your application contains multiple images that run on a single target, you can load all the images to the target. Each image must not overlap any of the other images.

To load a multi-image application:

1. Load the first image.
2. Load any subsequent images, and make sure that the **Replace Existing File(s)** check box is not selected on the Select Local File to Load dialog box.

See also

- *Loading an image directly* on page 3-11
- the following in the *RealView Debugger User Guide*:
 - Chapter 4 *Loading Images and binaries*
 - Chapter 7 *Debugging Multiprocessor Applications*

3.6 Setting a simple breakpoint

A breakpoint enables you to stop image execution at a point of interest, so that you can examine various parts of your application at that point.

3.6.1 Procedure

To set a simple breakpoint:

1. Select the Sources entry in the Process Control pane.
2. Type the characters dh. The source file dhry.h is selected.
3. Double-click on the source file dhry_1.c. The source file is opened.
4. Click **Locate PC** in the Debug toolbar. The PC is located in the source file, shown in Figure 3-7.





Figure 3-7 PC located in a source file

5. Scroll down until line 149 is visible.
6. Double-click in the gray margin at line 149. A simple breakpoint is set at line 149, as indicated by a red circle shown in Figure 3-8 on page 3-15.



```

File dhry_1.c Find Line Scripts <None>
144 #endif
145
146 for (Run_Index = 1; Run_Index <= Number_Of_Runs; ++Run_Index)
147 {
148
149 * Proc_5();
150 Proc_4();
151 /* Ch_1_Glob == 'A', Ch_2_Glob == 'B', Bool_Glob == true */
152 Int_1_Loc = 2;
153 Int_2_Loc = 3;
154 strcpy (Str_2_Loc, "DHRYSTONE PROGRAM, 2'ND STRING");

```

Home Page Disassembly dhry_1.c

Figure 3-8 Simple breakpoint set

Because the breakpoint location is in RAM, RealView Debugger sets a software breakpoint.

7. Run the image.

See also

- *Running the image* on page 3-16
- Chapter 11 *Setting Breakpoints* in the *RealView Debugger User Guide*.

3.7 Running the image

To run an image, either:

- Select **Run** from the **Debug** menu.
- Click the **Run** button on the Debug toolbar.



The Code window is updated as follows:

- the processor status changes to Running, and includes an animated progress indicator
- the process information in the Process Control pane is updated to show that the image is running
- the **StdIO** tab of the Output pane is selected, and application messages and prompts are displayed
- the CLI prompt in the **Cmd** tab of the Output pane changes to Run>.

3.7.1 Continuing the tutorial

If you are running the Dhrystone example described in *Setting a simple breakpoint* on page 3-14, then continue this tutorial as follows:

1. Run the `dhrystone.axf` image:
 - a. Click the **Run** button to start execution.
 - b. Enter the required number of runs, for example `20000`.

When the breakpoint that you set in *Setting a simple breakpoint* on page 3-14 is reached:

- A red box is drawn around the source line to show that the PC is pointing to this location.
 - Messages are displayed in the **Cmd** tab in the Output pane, to show what caused the execution to stop, and the location. In this case:
Stopped at 0x00008480 due to SW Instruction Breakpoint
Stopped at 0x00008480: DHRYS_1\main Line 149
2. You can now do the following:
 - Examine any variables that are in scope. For example, double-click on the variable `Int_2_Loc`, then drag and drop it onto the Watch pane.
 - Step through the image. For example, select **Step Into** from the Code window **Debug** menu.

- Click the **Run** button to restart execution until the breakpoint is reached again.
- Double-click on the red breakpoint indicator to clear the breakpoint, then click the **Run** button to restart execution.

See also

- *Setting a simple breakpoint* on page 3-14
- Chapter 9 *Executing Images* in the *RealView Debugger User Guide*.

3.8 Unloading an image

RealView Debugger automatically unloads an image from a debug target when you:

- disconnect from the debug target
- exit RealView Debugger.

However, you might want to unload an image explicitly as part of your debugging session, for example if you correct coding errors and then rebuild outside RealView Debugger.

You do not have to unload an image from a debug target before loading a new image for execution. Display the Select Local File to Load dialog box and make sure that the **Replace Existing File(s)** check box is selected.

3.8.1 How to explicitly unload an image

You can unload an image by using the Process Control pane. To do this:

1. If the Process Control pane is hidden, select **Process Control** from the default Code window **View** menu.

———— **Note** —————

If you still have the default panes visible in the Code window, then you do not have to do this step.

2. Right-click on either the Image or Load entry to display the context menu.
3. Select **Unload** from the context menu.

Alternatively, in the Process Control pane unselect the check box associated with the Load entry.

———— **Note** —————

Unloading an image does not affect target memory. It unloads the symbols and removes most of the image details from RealView Debugger. However, the image name is retained.


To remove image details completely, right-click on either the Image or Load entry in the Process Control pane and select **Delete Entry** from the context menu.

See also

- *Loading an image directly* on page 3-11
- Chapter 4 *Loading Images and binaries* in the *RealView Debugger User Guide*.

3.9 Disconnecting from a target

You can disconnect from the current target in one of the following ways:

- Select **Disconnect** from the Code window **Target** menu.
This immediately disconnects the connection shown in the Code window title bar.
-  Click the **Disconnect** button on the Connect toolbar.
This immediately disconnects the connection shown in the Code window title bar.
- Do the following:
 1. Select **Connect to Target...** from the Code window **Target** menu to display the Connect to Target window.
 2. Right-click on the required connection to display the context menu
 3. Select **Disconnect** from the context menu.



You can also click the **Connect** button on the Connect toolbar to display the Connect to Target window.

RealView Debugger Code windows do not close when you disconnect from a target. However, if you have an image loaded, disconnecting removes all the debug information from RealView Debugger and this clears pane contents.

Disconnecting changes the Processor status to Unknown, and the CLI prompt changes to None>.

———— Note —————

You do not have to disconnect from a target before you close down RealView Debugger.

3.9.1 See also

- *Exiting RealView Debugger* on page 3-20.
- Chapter 3 *Target Connection* in the *RealView Debugger User Guide*.

3.10 Exiting RealView Debugger

This section describes the options available when you exit RealView Debugger.

If you chose to save the current state of your Code window and connection when you exit RealView Debugger, then next time you start RealView Debugger:

- the Code window appears in the same state as your previous debugging session
- RealView Debugger automatically attempts to reconnect to a debug target, if it was previously connected when you last exited RealView Debugger.

3.10.1 Closing down RealView Debugger

To exit RealView Debugger:

1. Select **Exit** from the **File** menu to display the Exit dialog box.
2. Click **Yes** to close the Exit dialog box and close down RealView Debugger.

If any connections are still established, RealView Debugger stores the connection details, disconnects from the connected targets, and exits. When you next start RealView Debugger, these connections are re-established.

3.10.2 Reconnecting to a target

RealView Debugger saves all open connections in the current workspace if you close down without disconnecting first. This means that RealView Debugger tries to reconnect when you next open the workspace. However, this might fail if the connection or Debug Interface status has changed, for example if your RealView ICE interface unit has been disconnected.

If RealView Debugger reconnects successfully, the connection mode specified in the target configuration file is used by default.

See also

- Chapter 3 *Target Connection* in the *RealView Debugger User Guide*.

3.11 Cleaning up after the tutorial

If you created the tutorial project directory described in *Starting the tutorial* on page 3-3 you might want to remove it from your workstation. Do this in the usual way.

3.12 Localizing the RealView Debugger interface

By default, the RealView Debugger interface is configured for the US English language. However, you can configure the language for the RealView Debugger interface to Japanese.

If you do not want to change the internationalization settings, then you can skip this section.

3.12.1 Font recommendations

If you are changing the language to Japanese then it is recommended that you also change the font to **MSGothic** or **MSMincho**.

See also

- *Configuring the internationalization settings* on page 3-23.

3.12.2 Procedure summary

To localize the RealView Debugger interface, you must:

1. Configure the internationalization settings.
2. Configure the panes that display normal text to show the text in the correct text encoding.

Images built from C or C++ sources must be compiled with the `Multibyte_chars` project setting enabled (that is, the `--multibyte_chars` compiler option). You can optionally set the `Multibyte_locale` project setting (that is, the `--locale` compiler option). To build your image either:

- create an Eclipse project
- create a makefile.

See also

- *Configuring the internationalization settings* on page 3-23
- *Configuring the pane views* on page 3-24
- Chapter 3 *Target Connection* in the *RealView Debugger User Guide*.
- *RealView Compilation Tools Essentials Guide*
- *RealView Development Suite Eclipse Plug-in User Guide*
- *Eclipse IDE Guide*.

3.12.3 Configuring the internationalization settings

You can set the internationalization settings using:

- Global settings, if you have a shared RealView Debugger environment, and you want all users to use the same configuration. To do this, select **Options...** from the RealView Debugger **Tools** menu.

The Options window is displayed.

- Individual workspace settings, for individual users. To do this, select the following option from the RealView Debugger main menu:

File → **Workspace** → **Workspace Options...**

The Workspace Options window is displayed.

You can use the following procedure to edit the internationalization settings for both global and workspace settings:

1. Expand the following groups in the left pane:
 - ...\\rvdebug.ini
 - ALL
 - Text
2. Select the Internationalization group in the left pane.
3. Change the settings to the required values:
 - a. Right-click on the Enabled setting, and select **True** from the context menu
 - b. Right-click on the Language setting, and select the required language from the context menu, **English** or **Japanese**.
 - c. Right-click on the Default_encoding setting, and select the required encoding from the context menu, either **ASCII**, **UTF-8**, or **Locale**.
4. Select the Font_information group in the left pane.
5. Change the settings to the required values:
 - a. Right-click on the Pane_font setting, and select **Edit as font...** from the context menu. The Font dialog box is displayed.
 - b. In the Font dialog box, change the font to that required for your language.
 - c. Set up the remaining font settings as required. For the Japanese language, select either **MSGothic** or **MSMincho**.
 - d. Click **OK** to close the Font dialog box.
6. Select **Save and Close** from the **File** menu to save your changes and close the settings window.

7. Select **Exit** from the **File** menu to exit RealView Debugger.
8. Start RealView Debugger again.

In the Code window, an Encoding field is now displayed in the Find toolbar, shown in Figure 3-9.



Figure 3-9 Find toolbar with Encoding field

See also

- *Starting RealView Debugger* on page 3-4.

3.12.4 Configuring the pane views

To display messages and variable contents correctly in the Code window, you must set the encoding format to the format you specified in the settings window. You can change the format only for the following elements in the Code window:

- **Disassembly** tab, source code tabs, and text searches
- Output pane, all tabs
- individual variables in a Watch pane tab
- individual variables in the **Locals** tab and **Statics** tab of the Locals pane.

Changing the encoding format for the source code view and searches

To change the encoding format for the source code view, click the down arrow in the Encoding field on the Find toolbar, and select the required encoding, for example, **UTF-8**.

This also enables you to search your sources for multibyte text that matches the selected format.

Changing the encoding format for the Output pane

To change the encoding format for the Output pane:

1. Right-click in the Output pane to display the context menu.
2. Select **Format...** from the context menu to display the List Selection dialog box.
3. Select the required encoding from the dialog box, for example, **UTF-8**.
4. Click **OK**.

Changing the encoding format for individual Watch pane entries

To change the encoding for an individual Watch pane entry:

1. Right-click on the Watch entry to display the context menu.
2. Select **Format...** from the context menu to display the List Selection dialog box.
3. Select the required encoding from the dialog box, for example, **UTF-8**.
4. Click **OK**.

Changing the encoding format for individual Locals pane entries

To change the encoding for an individual Locals pane entry in either the **Locals** tab or the **Statics** tab:

1. Select **Locals** from the **View** menu to display the Locals pane.
2. Select the required tab in the Locals pane, for example **Locals**.
3. Right-click on an entry in the tab to display the context menu.
4. Select **Format...** from the context menu to display the List Selection dialog box.
5. Select the required encoding from the dialog box, for example, **UTF-8**.
6. Click **OK**.

See also

- *Configuring the internationalization settings* on page 3-23.

3.13 Saving a debugging session

RealView Debugger stores session details by default when you end your debugging session. Saving the session enables you to start your next session using the same working environment, and connecting automatically to specific targets.

3.13.1 Workspace

The RealView Debugger workspace is used for visualization and control of default values, and storing persistence information. It includes:

- user-defined options and settings
- connection details
- details about open windows and, in some cases, their contents.

The first time you run RealView Debugger, the default workspace settings file `rvdebug.aws` is created in your home directory. Each time you start RealView Debugger after this, the debugger loads this workspace automatically, but you can change the defaults or create a new workspace of your own.

3.13.2 Startup file

The startup file contains a record of your last debugging session including:

- images and files loaded into RealView Debugger
- the list of all recently loaded files, for example source files
- the recent workspaces list
- the workspace to be used on startup, if specified
- workspace save and restart settings
- user-defined menu settings, for example pane format options.

By default, this file is called `rvdebug.sav`. The first time you exit RealView Debugger after performing an operation in the default Code window, a startup file is created in your home directory. From this point on, every time you close down RealView Debugger and exit, this startup file is updated. You can specify a different startup file, or none at all, by changing your workspace settings.

See also

- Chapter 17 *Configuring Workspace Settings* in the *RealView Debugger User Guide*.

3.13.3 History file

The history file contains a record of:

- Commands submitted during a debugging session, for example, changing directory, loading source files, loading an image for execution, or setting breakpoints.
- Data entries examined in the Code window during debugging.
- The Set Directory and Set File lists used in the various open dialog boxes, such as the Select File to Open or Select File to Include Commands from dialog boxes.
- Up to 32 personal favorites such as variables, data values, and breakpoints.

RealView Debugger creates the history file when you carry out any of these operations for the first time, and then exit RealView Debugger. By default, the file is called `exphist.sav` and is stored in your home directory. The file is updated at the end of all subsequent debugging sessions.

———— **Note** —————

If you are using RealView Debugger on Red Hat Linux, the history file is only created if you create and save a favorite, for example a breakpoint.

See also

- Appendix E *RealView Debugger on Red Hat Linux* in the *RealView Debugger User Guide*.

Appendix A

About Previous Releases

This appendix describes the major differences between the previous releases of RealView® Debugger. The changes are described in:

- *Changes between RealView Debugger v3.0 and v1.8* on page A-2
- *Changes between RealView Debugger v1.8 and v1.7* on page A-9
- *Changes between RealView Debugger v1.7 and v1.6.1* on page A-16.

A.1 Changes between RealView Debugger v3.0 and v1.8

This section describes the changes between RealView Debugger v3.0 and the previous release RealView Debugger v1.8.

A.1.1 TrustZone support

RealView Debugger provides support for processors that implement the TrustZone® architecture. The impact on RealView Debugger is as follows:

- The Analysis window identifies Secure world (S:) and Normal world (N:) addresses when trace information is collected from a processor that supports the TrustZone architecture.
- When specifying addresses in dialog boxes or CLI commands you can include an address prefix to indicate either a Secure (S:) or Normal (N:) world address, see:
 - *Trace CLI commands* on page A-7
 - *Other CLI commands* on page A-7.
- The RealView Debugger windows and panes that display addresses also show the Secure (S:) or Normal (N:) world address prefix:
 - Analysis window
 - **Dsm** tab
 - Break/Tracepoints pane
 - Call Stack pane
 - Memory pane
 - Stack pane
 - Symbols pane.

A.1.2 Thumb-2EE Support

RealView Debugger provides support for *Thumb®-2 Execution Environment* (Thumb-2EE) enabled targets, such as Cortex-A8. For these targets:

- The following files are provided with RealView Debugger:
 - thumb2ee.bcd
 - thumb2ee.inc.

See the *RealView Debugger Target Configuration Guide* for more details about these files.

- You can now change the display of disassembly listings to Thumb-2EE format, using one of the following methods:
 - the **Set Disassembly Format...** option on the context menu in the disassembly view, that is, the **Dsm** tab (see the *RealView Debugger User Guide*)
 - the workspace (see the *RealView Debugger User Guide*)
 - the **SETTINGS CLI** command (see the *RealView Debugger Command Line Reference Guide*).

A.1.3 OS support

Operating system (OS) application debugging has been enhanced. For those OS plug-ins that support the enhancements, such as Linux HSD, you can now perform the following debugging operations:

- capture events that are defined by your OS plug-in
- specify filters that enable you to selectively load debugging symbols.

To configure these operations, the following options are available on the connection context menu in the Resource Viewer pane:

- **Events Filter...**
- **Debug Symbols Filter...**

Also, see *Changes to the CLI commands and predefined macros* on page A-6 for details of changes to the OS-related CLI commands.

See the *RealView Debugger RTOS Guide* for full details of debugging OS-aware targets in RealView Debugger.

A.1.4 Trace, Analysis, and Profiling

The following changes have been made to the trace, analysis, and profiling features:

- *Embedded Trace Macrocell™* (ETM) configuration enables you to specify:
 - values for extended external inputs 1-4, for ETMv3.1 and later
 - a synchronization frequency, for ETMv2 and later.
- You can now set tracepoints using extended external inputs 1 to 4, for ETMv3.1 and later.
- The details view has been removed from the Analysis window, together with the corresponding option on the **View** menu.

- The following changes have been made to the Analysis window **Filter** menu:
 - the **Invert Filtering (NOT)** option is now included
 - the **AND Filters (versus OR)** option is now two separate options, **OR All Filters** and **AND All Filters**
 - the **Filter on Raw Address Match...** option has been removed.
 - the text Match has been removed from all option names.
- The following changes have been made to the Analysis window **Find** menu:
 - the **Find Raw Address Match...** option has been removed
 - the text Match has been removed from all option names.
- The **Print Trace Lines...** option has been removed from the Analysis window **File** menu.
- The Set Address/Data Break/Tracepoint dialog box has been replaced with the Set/Edit Tracepoint dialog box.

Also, see *Changes to the CLI commands and predefined macros* on page A-6 for details of changes to the trace-related CLI commands.

See the *RealView Debugger Trace User Guide* for full details of tracing in RealView Debugger.

A.1.5 RealView Simulator Broker support

RealView Simulator Broker (RVBroker) has been re-engineered. Although RealView Debugger still runs RVBroker automatically for local host connections, starting RVBroker for remote connections has changed. You must now specify a username when starting RVBroker manually. See the *RealView Debugger Target Configuration Guide* for more details.

A.1.6 Multi-ICE direct connect

Connections using Multi-ICE[®] direct connect are no longer supported. Therefore, you cannot use Multi-ICE to connect to DSP targets. To debug a DSP target use RealView-ICE, which you must purchase separately.

A.1.7 Simulator support

The following simulated targets are now supported:

- An MPCore[™] simulated target is now supported in *RealView ARMulator[®] ISS* (RVISS). However, this simulates only a single processor.

- New *Instruction Set System Model* (ISSM) simulator models are now supported for the following processors:
 - Cortex™-A8
 - Cortex-M3.

A single ISSM Target Access is provided, which you can configure to either of these processors. If you want to simulate additional processors, you must create and configure a new Target Access for each processor.

See the *RealView Debugger Target Configuration Guide* for more details about configuring these simulated targets.

A.1.8 Changes to the GUI

The following changes have been made to the RealView Debugger GUI:

- The Connection Control window has been re-engineered to simplify the connection and configuration of debug targets.
- The **Synch** tab on the older Connection Control window is now a separate Synchronization Control window. To display the Synchronization Control window, select **Synchronization Control...** from the Code window **Target** menu.
- All references to *software interrupt* (SWI) have been changed to *Supervisor Call* (SVC).
- The project management feature has been removed. Therefore:
 - the Code window **Project** menu has been removed
 - the source control toolbar button has been removed
 - you cannot load RealView Debugger project files.

However, the source code edit and search features are still available.

- There is a new Load Binary dialog box that simplifies the loading of binary files. To display the Load Binary dialog box, select **Load Binary...** from the Code window **Target** menu.
Binary files you load in this way are added to the Recent Binaries list. To display the Recent Binaries list, select **Recent Binaries** from the Code window **Target** menu.
- The Set Address/Data Break/Tracepoint dialog box has been replaced with the following dialog boxes:
 - Create Breakpoint
 - Copy Breakpoint
 - Edit Breakpoint

- Set/Edit Tracepoint.
- The Registers pane has been re-engineered:
 - The individual fields of the CPSR and SPSR registers are no longer shown as individual registers. To change these registers, a PSR Format dialog box is provided.
 - Extended formatting options are now available for all registers.
 - Registers that have enumerated values appear as list selection boxes.
 - You can now create your own user-specific register view by copying registers from the other tabs in the Registers pane.
- The Data Navigator pane is now called the Symbols pane. To display the Symbols pane, you now select **Symbols** from the Code window **View** menu.
- The Symbol Browser pane is now called the Classes pane. To display the Classes pane, you now select **Classes** from the Code window **View** menu.
- The Flash Memory Control dialog box now includes a field that enables you to specify the clock frequency, if supported by your Flash device. See the *RealView Debugger Target Configuration Guide* and the *RealView Debugger User Guide* for more details.
- The Resource Viewer window is now a pane, which you can float and dock like any other pane.

See the *RealView Debugger User Guide* for more details about how to use these features.

A.1.9 Changes to the CLI commands and predefined macros

This section describes the changes that have been made to the CLI commands and predefined macros.

See the *RealView Debugger Command Line Reference Guide* for full details.

Connection CLI commands

The following change has been made to the connection CLI commands:

- The DISCONNECT command now has the debug and nodebug qualifiers for specifying the disconnect mode.

OS-aware CLI commands

The following change has been made to the OS-aware CLI commands:

- If your OS-aware plug-in supports event debugging, then the `OSCTRL` command enables you to specify events and filters for the selective loading of debugging symbols.

See the *RealView Debugger RTOS Guide* for more details on using the events and filters.

Trace CLI commands

The following changes have been made to the trace CLI commands:

- The `TRACEDATAACCESS`, `TRACEDATAREAD`, `TRACEDATAWRITE`, `TRACEINSTREXEC`, and `TRACEINSTRFETCH` commands enable Secure world and Normal world data comparisons for processors that implement the TrustZone architecture.
- The `TRACEEXTCOND` command supports extended external inputs 1 to 4, for ETMv3.1 and later.
- The `TRACEBUFFER` command includes an option to invert the sense of the specified filter conditions.
- The `ETM_CONFIG` command enables you to specify:
 - values for extended external inputs 1 to 4, for ETMv3.1 and later
 - a synchronization frequency, for ETMv2 and later.

Other CLI commands

The changes made to other CLI commands are as follows:

- the `BREAKACCESS`, `BREAKEXECUTION`, `BREAKINSTRUCTION`, `BREAKREAD`, and `BREAKWRITE` commands enable you to specify an address prefix to identify Secure world and Normal world addresses on a TrustZone-enabled target
- the `DISASSEMBLE` command enables you to show Thumb-2EE disassembly
- the `LOAD` command enables you to load images to either the Secure or Normal world on a TrustZone-enabled target
- the access size options of the `READFILE`, `VERIFYFILE`, and `WRITEFILE` commands have changed
- the `SETTINGS` command no longer supports the project-related settings
- a new `STATS` command enables you to display bus and processor cycles for RVISS targets.

Predefined macros

The following change has been made to the predefined macros:

- There is a new `fclose` macro to complement the `fopen` macro.

A.1.10 Updated documentation

The following changes have been made to the RealView Debugger documentation:

- The documentation suite now comprises the documents listed in *RealView Development Suite Documentation*.
- The *RealView Debugger User Guide* is now task-based.
- The chapter that describes target connection in the *RealView Debugger Target Configuration Guide* has been incorporated into the *RealView Debugger User Guide*.
- The *RealView Debugger Extensions User Guide* has been removed. The contents of the *RealView Debugger Extensions User Guide* are now in the following documents:
 - the chapter and appendixes that describe tracing are now in the new document *RealView Debugger User Guide*
 - the chapter that describes OS support is now in the new document *RealView Debugger RTOS Guide*
 - the chapter that describes multiprocessor debugging has been incorporated into the *RealView Debugger User Guide*
 - the chapter that describes DSP support has been incorporated into the *RealView Debugger User Guide*.
- The *RealView Debugger Project Management User Guide* is no longer provided.

A.2 Changes between RealView Debugger v1.8 and v1.7

This section describes the changes between RealView Debugger v1.8 and the previous release RealView Debugger v1.7.

A.2.1 Updated documentation

The changes to the documentation includes the following:

- There is a new chapter about programming Flash in the *RealView Debugger Target Configuration Guide*. This chapter describes in detail how to create the files required to program Flash with RealView Debugger, whether you are using the Flash devices and boards currently supported by RealView Debugger, or your own custom Flash devices and boards.
- The *RealView Debugger Essentials Guide* now includes:
 - all information that relates to moving from ARM[®] *eXtended Debugger* (AXD) or *ARM Symbolic Debugger* (armsd) to RealView Debugger
 - background information about RealView Debugger projects, and how to set up the basic compilation tasks for a project
 - details on how to get started using the RealView Debugger CLI
 - an appendix showing the mapping of the main menu options to the toolbar buttons.
- The task-related information from the *RealView Debugger Command Line Reference Guide* is now in the chapter that describes getting started using the RealView Debugger CLI in the *RealView Debugger Essentials Guide*.
- Enhancements to tracing with RealView Debugger have been documented (see *Trace, Analysis, and Profiling* for a summary).
- All documents now reflect the enhancements to the RealView Debugger GUI (see *Changes to the GUI* on page A-10 for a summary).
- The RealView Debugger online help is now in HTML format, and is displayed using your default web browser.

A.2.2 Trace, Analysis, and Profiling

RealView Debugger v1.8 includes enhancements to the Trace and profiling features:

- tracepoints are now categorized as unconditional or conditional
- the Analysis window has changed (see *Changes to the Analysis window* on page A-10 for a summary of the changes)

- the Configure ETM dialog has changed to support the new *Embedded Trace Macrocell*[™] v3 (ETMv3), ETB11[™] port widths (24-bit and 32-bit)
- there is a new trace command, TRACEEXTCOND.

Changes to the Analysis window

The changes to the Analysis window include:

- the following new features:
 - display of interleaved inferred register values
 - functionality to sum profiling data over a number of runs
 - rationalization of the window tabs
- the following improvements:
 - block fetching of trace data, to enhance performance
 - changes to column layouts and the addition of new columns
 - new options in the profiling window.

These changes have the following implications:

- sorting of trace data is supported only in the **Profile** tab
- appending trace data is no longer supported.

For full details on tracing with RealView Debugger, see the *RealView Debugger Extensions User Guide*.

A.2.3 Support for gcc built images

RealView Debugger supports images built with gcc as follows:

- Images built with gcc v3.2 and v3.4 are fully supported.
- Images built with gcc v2.95.3 are supported, but with no stack backtrace. In addition, these images require converting to ELF format using the `coff2elf` utility. You can obtain this utility from the ARM Technical Support web page.

A.2.4 Changes to the GUI

This section describes the major changes to the RealView Debugger GUI.

Changes to the Code window main menu structure

The Code window main menus have been restructured, with new menus added, and menu options moved to reflect their functionality:

- File** The following changes have been made to this menu:
- the image load options are now available on the new **Target** menu
 - connections are now available on the new **Target** menu
 - logs and journals are now available on the **Tools** menu
 - all workspace-related options are now available from the **Workspace** submenu.

———— **Note** ————

The **Threads** menu option has been removed, because this feature is available using the **Cycle Threads** toolbar button.

- Edit** All editing-related functionality is now available from this menu, including copying and pasting, and searching. The changes include the following:
- the new **Advanced** submenu contains the options from the old **Format** and **Editing Controls** submenus
 - the new **Go To** submenu contains the original **Jump** options.
 - removal of some little-used options, such as **VI mode**.
- View** All pane views are now accessible from the main **View** menu, instead of the **New Pane Views** submenu. A new Data Navigator option is available to display the Data Navigator pane. The Browse Symbols dialog box is replaced by a Symbol Browser pane, which has enhanced functionality.
- Target** This is a new menu that includes all options relating to connections and image loading.
- Project** This menu contains all the project-related options available in previous versions of RealView Debugger, but the grouping has changed.
- Build** This is a new menu that includes all the build-related options from the **Tools** menu.
- Debug** The following changes have been made to this menu:
- the options on the **Execution Control** are now available on the main **Debug** menu.

- the breakpoint options are combined into a single **Breakpoints...** submenu
- the **Debug/Simple Breakpoints** submenu options are redistributed between the new **Breakpoints** submenu and the new **Breakpoints → Conditional** submenu
- the **Complex Breakpoints** submenus options are now available from the **Breakpoints → Hardware...** submenu
- the **Processor Events** option is now available from the option **Processor Exceptions...**
- the **Include Commands from File...** option is now available on the **Tools** menu.

Tools The following changes have been made to this menu:

- the build-related options are now available on the new **Build** menu
- the workspace options are now available from the **File → Workspace** menu
- a new **Logs and Journal** submenu is available for opening and closing log and journal files
- the **Include Commands from File...** option has been moved to this menu from the **Debug** menu
- the **New Editor** submenu has been removed.

Help The following changes have been made to this menu:

- all web-related options are now on the **ARM on the Web** submenu
- the **Full Online Documentation** option has been removed
- access to the RealView Debugger online help is simplified, and is now available through the **RealView Debugger Help** option.

Toolbar changes

The Code window toolbar is now split into separate function-specific toolbars. Each toolbar can be hidden, moved, or floated independently. The toolbars are:

- File
- Edit
- Debug
- Image
- Connect
- Build
- Find.

Internationalization is now supported

Internationalization is now supported, so that you can localize the RealView Debugger interface. You can:

- set the language to English (the default), or Japanese
- set the default encoding to ASCII (the default), UTF-8, or Locale.

This displays the main menu and various context menu options in the chosen language. For instructions on how to change these settings, see the *RealView Debugger User Guide*.

Changes to pane views

The following changes have been made to panes in RealView Debugger:

- You now have greater flexibility over the docking of panes.
- All panes, except for the File Editor pane, can be floated, hidden, and repositioned on the RealView Debugger desktop.
- You can now set the font used in the pane views. You can set the font name, style, size, and script.
- There is a new Data Navigator pane that enables you to quickly locate a module, function, or variable in an image.
- The Browse Symbols dialog box is replaced by a Symbol Browser pane, which has enhanced functionality.
- The **Expand/Collapse Pane** button has been removed from the pane toolbar.

Changes to breakpoints

Breakpoints are no longer categorized as Simple and Complex. They are now categorized as Software and Hardware, and as unconditional or conditional. As a consequence, the names of the various dialog boxes used to set breakpoints have changed. See the *RealView Debugger User Guide* for more details.

The Set Address/Data Break/Tracepoint dialog box can now only be used to set breakpoints. Therefore, this dialog box is now called Set Address/Data Breakpoint.

Named breakpoints are no longer supported. Although the Named_breaks group is still present in the Project Properties, the **Named...** menu option has been removed. The Named_breaks group is to be removed in a future release.

Changes to tracepoints

The following changes have been made to tracepoints:

- Tracepoints are no longer categorized as Simple and Complex. They are now categorized as unconditional or conditional.
- You can no longer use the Set Address/Data Break/Tracepoint dialog box to set tracepoints. Therefore, this dialog box is now called Set Address/Data Breakpoint.

See the chapter that describes tracing in RealView Debugger in the *RealView Debugger Extensions User Guide* for more details.

Changes to editing facilities

The following changes have been made to the editing facilities in RealView Debugger:

- You now have more control over source code coloring. You can:
 - set both the foreground text color and the background color for various code elements
 - choose the default colors from a list of color schemes, such as Visual Studio
 - set colors for the additional code element identifiers, preprocessor keywords, and operators.
- You can now set the font used in the pane views. You can set the font name, style, size, and script.
- The standalone Editor window has been removed. Also, there is no longer support for using personal standalone editors with RealView Debugger.
- You can no longer use Vi mode when editing.

A.2.5 Changes to the CLI

The following changes have been made to the CLI:

- Spaces are no longer allowed in connection names. Therefore, the RealView ICE is now called RealView-ICE.
- A new CLI command PRINTDSM is available to disassemble the contents of target memory to the **Cmd** tab of the Output pane. The disassembly is in the same format as that shown in the **Dsm** tab of the File Editor pane. Therefore, if you have a journal file open, you can output the disassembly to a file.

- A new trace command, TRACEEXTCOND, is available to set a tracepoint that triggers when an instruction in the specified address range is executed.
- The switches /MB and /R have been added to the PRINTVALUE command:
 - /MB enables multibyte character values to be displayed correctly
 - /R prevents the address being displayed when you specify a variable in a loaded image.
- A /S switch has been added to the INCLUDE command to stop the CLI commands being echoed to the display.
- The ETM_CONFIG command now supports the ETB11 port widths.

A.2.6 RealView ARMulator ISS support

Map files are now supported for *RealView ARMulator*[®] ISS (RVISS) connections through the Simulator Broker interface.

A.2.7 RealMonitor support

You can now use RealMonitor with RealView ICE connections. Also, how you configure a Multi-ICE[®] connection to use RealMonitor has changed.

For details on how to configure and use RealMonitor with RealView ICE and Multi-ICE, see the *RealView Debugger Target Configuration Guide*.

A.3 Changes between RealView Debugger v1.7 and v1.6.1

This section describes the changes between RealView Debugger v1.7 and the previous release RealView Debugger v1.6.1.

A.3.1 Updated documentation

The documentation for developers using RealView Debugger on Windows has been updated to include enhancements and new features in RealView Debugger v1.7. See:

- *RealView Debugger Essentials Guide* for updated information for developers moving to RealView Debugger from AXD.
- The detailed description of project management in RealView Debugger has been moved from *RealView Debugger User Guide* to a new book called *RealView Debugger Project Management User Guide*.
- *RealView Debugger User Guide* for information for developers using RealView Debugger on non-Windows platforms. See Appendix B *RealView Debugger for Sun Solaris and Red Hat Linux* for details.

A.3.2 Advanced debugging facilities

RealView Debugger v1.7 enables you to connect to a RealView ICE target using RealView ICE.

A.3.3 RealView ARMulator ISS

In RealView Developer Suite (RVDS), *RealView ARMulator ISS* (RVISS) replaces *ARM Developer Suite™* (ADS) ARMulator.

RVISS enables your debugger to connect using the *Remote Debug Interface* (RDI) and RealView Connection Broker interface. With RealView Connection Broker you connect to multiple instance of RVISS, and you can also connect to a remote RVISS that is on a different system to your debugger. For more details, see the *RealView ARMulator ISS User Guide*.

———— **Note** —————

The RDI connection to RVISS in RealView Debugger is deprecated in this release.

A.3.4 Trace, Analysis, and Profiling

RealView Debugger v1.7 includes enhancements to the Trace and profiling features, including changes to the:

- ETM configuration dialog
- way that trace information is displayed so that interleaved source can be viewed
- method for setting tracepoints
- Set Address/Data Break/Tracepoint dialog
- Analysis window (menu changes).

———— **Note** —————

RealView Debugger v1.7 enables you to access Trace and profiling features without having to purchase a separate license. These features are part of the core product.

A.3.5 Enhanced RTOS support

RealView Debugger v1.7 includes enhancements to RTOS awareness and visualization.

Running System Debug

Running System Debug (RSD) means that you can debug a target when it is running. This means that you do not have to stop your debug target before carrying out any analysis of your system. Where supported by your RTOS, RSD enables you to debug threads individually or in groups.

Thread-based breakpoints

RealView Debugger v1.7 enables you to use the Set Address/Data Break/Tracepoint dialog box and the Break/Tracepoints pane to set thread-based breakpoints when running in RSD mode.

RTOS visualization

This release sees new RTOS visualization features. This gives users an improved threads view in the Process Control pane and provides new menus and tabs in the Resource Viewer pane.

RTOS CLI commands

RealView Debugger v1.7 includes new RTOS resource commands that enable you to control RTOS awareness, manage breakpoints and resources, and perform operations on RTOS objects.

———— **Note** —————

RealView Debugger v1.7 does not support RTOS resource CLI commands of the form:

`D<resource-list>=expression`

Use `dos_<resource-list>` commands instead.

See the chapter that describes RTOS support in the *RealView Debugger Extensions User Guide* for full details of all the RTOS support provided by RealView Debugger v1.7.

A.3.6 New GUI elements

New toolbar buttons and menu changes mean that RealView Debugger v1.7 users now have quick access to commonly used features. The changes include:

- a new **Thread** menu, available from the main **File** menu, that replicates the drop-down menu from the **Cycle Threads** button
- a new Actions toolbar button to hide or display the Connection Control window
- a new Actions toolbar button to disconnect from a target.
- an addition to the Execution group, on the Actions toolbar, to execute a **Go to Cursor** operation.

RealView Debugger v1.7 also includes:

- the ability to choose which register is used as a stack pointer, indicated by a new Expression Pointer (EP).
- user-specified data display in the Stack pane
- type ahead for navigating sources and images in the Process Control pane
- persistence of source search paths and path mappings through project settings
- a new **Help** button on the Project Control dialog box
- improved error messages.