

RealView Developer Kit v2.2 for Philips

Installation Guide

Copyright © 2005 ARM Limited. All rights reserved.

Release Information

The following changes have been made to this book.

Change History

Date	Issue	Change
July 2005	A	RealView Developer Kit v2.2 for Philips release

Proprietary Notice

Words and logos marked with ® or ™ are registered trademarks or trademarks owned by ARM Limited. Other brands and names mentioned herein may be the trademarks of their respective owners.

Neither the whole nor any part of the information contained in, or the product described in, this document may be adapted or reproduced in any material form except with the prior written permission of the copyright holder.

The product described in this document is subject to continuous developments and improvements. All particulars of the product and its use contained in this document are given by ARM in good faith. However, all warranties implied or expressed, including but not limited to implied warranties of merchantability, or fitness for purpose, are excluded.

This document is intended only to assist the reader in the use of the product. ARM Limited shall not be liable for any loss or damage arising from the use of any information in this document, or any error or omission in such information, or any incorrect use of the product.

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by ARM and the party that ARM delivered this document to.

Product Status

The information in this document is final, that is for a developed product.

Web Address

<http://www.arm.com>

Contents

Supported platforms	1
Installing RealView Developer Kit v2.2 for Philips.....	2

1 Supported platforms

RealView Developer Kit v2.2 for Philips is supported on computer systems running:

- Windows XP Professional
- Windows 2000.

Note

RealView Developer Kit v2.2 for Philips uses FLEXlm license management software. See the *ARM FLEXlm License Management Guide* for more information.

2 Installing RealView Developer Kit v2.2 for Philips

To install RealView Developer Kit v2.2 for Philips:

1. Read the release notes for important information about this release.
2. Insert the CD into the CD-ROM drive. The ARM Installer should start automatically. If it does not start, execute the program `setup.exe` in the top-level directory of the CD-ROM.
3. Follow the prompts to install RealView Developer Kit v2.2 for Philips.
4. Choose the type of installation you require:
 - Typical** installs all components of RealView Developer Kit v2.2 for Philips.
 - Custom** enables you to choose which components of RealView Developer Kit v2.2 for Philips to install.
5. When the software installation is complete, the ARM License Wizard is launched. If you want to defer installing a license to a later time, click **Cancel**. Otherwise, follow the prompts to install your license file, or to submit a license request.

2.1 Requesting upgrade licenses

Contact your supplier for details of the upgrade licenses that you can purchase. For details about installing the licenses, see the *ARM FLEXIm License Management Guide*.

2.2 Uninstalling RealView Developer Kit v2.2 for Philips

Ensure that no RealView Developer Kit v2.2 for Philips component is running before you uninstall.

To uninstall RealView Developer Kit v2.2 for Philips:

1. Select **Start** → **Programs** → **ARM** → **Uninstallation Wizard** to launch the ARM Uninstaller.
2. Follow the prompts to uninstall RealView Developer Kit v2.2 for Philips.

Note

If you are using the default Windows XP settings, select **All Programs**.
